

inst.eecs.berkeley.edu/~cs61c  
**CS61C : Machine Structures**

## Lecture 13 – Introduction to MIPS Instruction Representation I



**Lecturer PSOE Dan Garcia**

[www.cs.berkeley.edu/~ddgarcia](http://www.cs.berkeley.edu/~ddgarcia)

**Anyone seen Terminator? ⇒**

**Military wants robot soldiers.**

**Let's see, they get to grow their budgets,  
and they intent to (years from now) use  
Berkeley's smart dust. Be very afraid.**



[www.nytimes.com/2005/02/16/technology/16robots.html](http://www.nytimes.com/2005/02/16/technology/16robots.html)  
CS61C L13 Introduction to MIPS: Instruction Representation I (1)

Garcia © UCB

# Overview – Instruction Representation

---

- **Big idea: stored program**
  - consequences of stored program
- **Instructions as numbers**
- **Instruction encoding**
- **MIPS instruction format for Add instructions**
- **MIPS instruction format for Immediate, Data transfer instructions**



# **Big Idea: Stored-Program Concept**

---

- **Computers built on 2 key principles:**
  - 1) Instructions are represented as numbers.**
  - 2) Therefore, entire programs can be stored in memory to be read or written just like numbers (data).**
- **Simplifies SW/HW of computer systems:**
  - **Memory technology for data also used for programs**



# Consequence #1: Everything Addressed

- **Since all instructions and data are stored in memory as numbers, everything has a memory address: instructions, data words**
  - both branches and jumps use these
- **C pointers are just memory addresses: they can point to anything in memory**
  - Unconstrained use of addresses can lead to nasty bugs; up to you in C; limits in Java
- **One register keeps address of instruction being executed: “Program Counter” (PC)**
  - Basically a pointer to memory: Intel calls it Instruction Address Pointer, a better name



## Consequence #2: Binary Compatibility

- **Programs are distributed in binary form**
  - Programs bound to specific instruction set
  - Different version for **Macintoshes** and **PCs**
- **New machines want to run old programs (“binaries”) as well as programs compiled to new instructions**
- **Leads to instruction set evolving over time**
- **Selection of Intel 8086 in 1981 for 1st IBM PC is major reason latest PCs still use 80x86 instruction set (Pentium 4); could still run program from 1981 PC today**



# Instructions as Numbers (1/2)

---

- **Currently all data we work with is in words (32-bit blocks):**
  - Each register is a word.
  - `lw` and `sw` both access memory one word at a time.
- **So how do we represent instructions?**
  - Remember: Computer only understands 1s and 0s, so “`add $t0, $0, $0`” is meaningless.
  - MIPS wants simplicity: since data is in words, make instructions be words too



## Instructions as Numbers (2/2)

---

- One word is 32 bits, so divide instruction word into “**fields**”.
- Each field tells computer something about instruction.
- We could define different fields for each instruction, but MIPS is based on simplicity, so define 3 basic types of instruction formats:
  - R-format
  - I-format
  - J-format



# Instruction Formats

---

- **I-format**: used for instructions with immediates, `lw` and `sw` (since the offset counts as an immediate), and the branches (`beq` and `bne`),
  - (but not the shift instructions; later)
- **J-format**: used for `j` and `jal`
- **R-format**: used for all other instructions
- It will soon become clear why the instructions have been partitioned in this way.





# R-Format Instructions (1/5)

- Define “**fields**” of the following number of bits each:  $6 + 5 + 5 + 5 + 5 + 6 = 32$

6	5	5	5	5	6
---	---	---	---	---	---

- For simplicity, each field has a name:

opcode	rs	rt	rd	shamt	funct
--------	----	----	----	-------	-------

- **Important:** On these slides and in book, each field is viewed as a 5- or 6-bit unsigned integer, not as part of a 32-bit integer.

- **Consequence:** 5-bit fields can represent any number 0-31, while 6-bit fields can represent any number 0-63.



## R-Format Instructions (2/5)

---

- **What do these field integer values tell us?**
  - **opcode**: partially specifies what instruction it is
    - **Note**: This number is equal to 0 for all R-Format instructions.
  - **funct**: combined with opcode, this number exactly specifies the instruction
- **Question**: Why aren't opcode and funct a single 12-bit field?
  - **Answer**: We'll answer this later.



# R-Format Instructions (3/5)

---

- **More fields:**
  - rs (**S**ource **R**egister): *generally* used to specify register containing first operand
  - rt (**T**arget **R**egister): *generally* used to specify register containing second operand (note that name is misleading)
  - rd (**D**estination **R**egister): *generally* used to specify register which will receive result of computation



# R-Format Instructions (4/5)

---

- **Notes about register fields:**
  - Each register field is exactly 5 bits, which means that it can specify any unsigned integer in the range 0-31. Each of these fields specifies one of the 32 registers by number.
  - The word “generally” was used because there are exceptions that we’ll see later. E.g.,
    - `mult` and `div` have nothing important in the `rd` field since the dest registers are `hi` and `lo`
    - `mfhi` and `mflo` have nothing important in the `rs` and `rt` fields since the source is determined by the instruction (p. 264 P&H)



# R-Format Instructions (5/5)

---

- **Final field:**
  - **shamt**: This field contains the amount a shift instruction will shift by. Shifting a 32-bit word by more than 31 is useless, so this field is only 5 bits (so it can represent the numbers 0-31).
  - This field is set to 0 in all but the shift instructions.
- **For a detailed description of field usage for each instruction, see green insert in COD 3/e**
  - (You can bring with you to all exams)



# R-Format Example (1/2)

---

- **MIPS Instruction:**

`add $8, $9, $10`

`opcode = 0` (look up in table in book)

`funct = 32` (look up in table in book)

`rd = 8` (destination)

`rs = 9` (first *operand*)

`rt = 10` (second *operand*)

`shamt = 0` (not a shift)



## R-Format Example (2/2)

---

- **MIPS Instruction:**

add \$8, \$9, \$10

Decimal number per field representation:

0	9	10	8	0	32
---	---	----	---	---	----

Binary number per field representation:

000000	01001	01010	01000	00000	100000
--------	-------	-------	-------	-------	--------

hex

hex representation: 012A 4020<sub>hex</sub>

decimal representation: 19,546,144<sub>ten</sub>

- Called a [Machine Language Instruction](#)



# Administrivia

---

- **Project 1 due Friday**
- **Homework 4 online soon**
  - **Andy is the TA in charge**
  - **It's only book exercises**
- **Dan's OH cancelled next week**
  - **He'll be presenting at SIGCSE**
  - **<http://www.ithaca.edu/sigcse2005/>**





# I-Format Instructions (1/4)

---

- **What about instructions with immediates?**
  - **5-bit field only represents numbers up to the value 31: immediates may be much larger than this**
  - **Ideally, MIPS would have only one instruction format (for simplicity): unfortunately, we need to compromise**
- **Define new instruction format that is partially consistent with R-format:**
  - **First notice that, if instruction has immediate, then it uses at most 2 registers.**



## I-Format Instructions (2/4)

---

- Define “fields” of the following number of bits each:  $6 + 5 + 5 + 16 = 32$  bits

6	5	5	16
---	---	---	----

- Again, each field has a name:

opcode	rs	rt	immediate
--------	----	----	-----------

- **Key Concept:** Only one field is inconsistent with R-format. Most importantly, opcode is still in same location.



# I-Format Instructions (3/4)

---

- What do these fields mean?
  - **opcode**: same as before except that, since there's no **funct** field, **opcode** uniquely specifies an instruction in I-format
  - This also answers question of why R-format has two 6-bit fields to identify instruction instead of a single 12-bit field: in order to be consistent with other formats.
  - **rs**: specifies the *only* register operand (if there is one)
  - **rt**: specifies register which will receive result of computation (this is why it's called the *target* register "rt")



# I-Format Instructions (4/4)

---

- **The Immediate Field:**
  - `addi`, `slli`, `slliu`, the immediate is **sign-extended** to 32 bits. Thus, it's treated as a signed integer.
  - 16 bits → can be used to represent immediate up to  $2^{16}$  different values
  - This is large enough to handle the offset in a typical `lw` or `sw`, plus a vast majority of values that will be used in the `slli` instruction.
  - We'll see what to do when the number is too big in our next lecture...



# I-Format Example (1/2)

---

- **MIPS Instruction:**

`addi $21, $22, -50`

`opcode = 8` (look up in table in book)

`rs = 22` (register containing operand)

`rt = 21` (target register)

`immediate = -50` (by default, this is decimal)



# I-Format Example (2/2)

---

- **MIPS Instruction:**

`addi $21, $22, -50`

**Decimal/field representation:**

8	22	21	-50
---	----	----	-----

**Binary/field representation:**

001000	10110	10101	1111111111001110
--------	-------	-------	------------------

**hexadecimal representation: 22D5 FFCE<sub>hex</sub>**

**decimal representation: 584,449,998<sub>ten</sub>**



# Peer Instruction

Which instruction has same representation as  $35_{\text{ten}}$ ?

1. add \$0, \$0, \$0

opcode	rs	rt	rd	shamt	funct
--------	----	----	----	-------	-------

2. subu \$s0,\$s0,\$s0

opcode	rs	rt	rd	shamt	funct
--------	----	----	----	-------	-------

3. lw \$0, 0(\$0)

opcode	rs	rt	offset		
--------	----	----	--------	--	--

4. addi \$0, \$0, 35

opcode	rs	rt	immediate		
--------	----	----	-----------	--	--

5. subu \$0, \$0, \$0

opcode	rs	rt	rd	shamt	funct
--------	----	----	----	-------	-------

6. Trick question!

Instructions are not numbers

Registers numbers and names:

0: \$0, .. 8: \$t0, 9:\$t1, ..15: \$t7, 16: \$s0, 17: \$s1, .. 23: \$s7

Opcodes and function fields (if necessary)

add: opcode = 0, funct = 32

subu: opcode = 0, funct = 35

addi: opcode = 8

lw: opcode = 35



## In conclusion...

---

- **Simplifying MIPS: Define instructions to be same size as data word (one word) so that they can use the same memory (compiler can use `lw` and `sw`).**
- **Computer actually stores programs as a series of these 32-bit numbers.**
- **MIPS Machine Language Instruction: 32 bits representing a single instruction**

R	opcode	rs	rt	rd	shamt	funct
I	opcode	rs	rt	immediate		

